



Thor-2-ExpressCard Technical Description

Doc. No. 1111-1-HAA-1074-1

Rev. 1.0



Copyright

© Copyright 2006, Odin TeleSystems, Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Odin TeleSystems Inc., 800 East Campbell Road, Suite 334, Richardson, Texas 75081, U. S. A.

Trademarks

Odin TeleSystems, the Odin Logo, OTX, and Thor-2-ExpressCard are trademarks of Odin TeleSystems Inc., which may be registered in some jurisdictions. Other trademarks are the property of their respective companies.

Changes

The material in this document is for information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, Odin TeleSystems Inc., assumes no liability resulting from errors or omissions in this document, or from the use of the information contained herein.

Odin TeleSystems Inc. reserves the right to make changes in the product design without reservation and notification to its users.

Warranties

THE PRODUCT AND ITS DOCUMENTATION ARE PROVIDED “AS IS” AND WITHOUT WARRANTY OF ANY KIND. ODIN TELESYSTEMS EXPRESSLY DISCLAIMS ALL THE WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE. ODIN TELESYSTEMS DOES NOT WARRANT THAT THE FUNCTIONALITY OF THE PRODUCT WILL MEET ANY REQUIREMENTS, OR THAT THE OPERATIONS OF THE PRODUCT WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS WILL BE CORRECTED. FURTHERMORE, ODIN TELESYSTEMS DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OF THE PRODUCT OR ITS DOCUMENTATION IN TERMS OF THEIR CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVISE GIVEN BY ODIN TELESYSTEMS OR ODIN TELESYSTEMS’ AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY.

UNDER NO CIRCUMSTANCE SHALL ODIN TELESYSTEMS INC., ITS OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS, PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT AND ITS DOCUMENTATION, EVEN IF ODIN TELESYSTEMS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL ODIN TELESYSTEMS’ LIABILITY FOR ANY REASON EXCEED THE ACTUAL PRICE PAID FOR THE PRODUCT AND ITS DOCUMENTATION. SOME JURISDICTIONS DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY.



Table of Contents

1	Abstract.....	5
2	Thor-2-ExpressCard Overview.....	5
3	Physical specifications.....	5
4	Data Architecture.....	6
4.1	Outgoing Data	7
4.2	Incoming Data	9
5	T1 / E1 Interface Connections.....	10
6	API Supported Physical Devices.....	10
6.1	Board Device (OTX_DEVICE_THOR_2_PCI_EXPRESS)	10
6.2	Dual T1/E1/J1 Device (OTX_DEVICE_DUAL_T1E1)	11
6.3	T1/E1/J1 Line Interface Devices (OTX_DEVICE_LI_T1E1).....	11
6.4	Burst Device (OTX_DEVICE_BURST).....	11
6.5	DSP (OTX_DEVICE_DSP).....	11
7	Line Interface Functionality.....	12
7.1	Line Configurations.....	12
7.2	Fault Monitoring.....	12
7.3	Loop Back	13
8	Testing features	13
9	ExpressCard Interface.....	13
10	Clocks	13
11	JTAG	14
12	Power	14



13	Certifications.....	14
14	Reference documents.....	14
15	Glossary	14



1 Abstract

This document provides a technical description of Odin TeleSystems' Thor-2-ExpressCard adapter card. This presentation is targeted to systems integrators and application developers who are developing telecommunications systems and/or software applications using the Thor-2-ExpressCard product. The purpose of this document is to provide the needed information about the hardware to allow software developers to efficiently integrate Thor-2-ExpressCard into their overall system under design.

For information on how to develop host applications utilizing the OTX Hardware Device Driver Application Programming Interface (API), please refer to the "Programmer's Guide for OTX Hardware API" document (Odin TeleSystems Inc. document number 1411-1-SAA-1006-1). For information on how to develop custom DSP applications, please refer to "Programmer's Guide for OTX C54x DSP Software Development Kit" (Odin document number 1412-1-SAA-1007-1). And finally, for help on how to install the Thor-2-ExpressCard card and the OTX Device Driver Software, please refer to the Installation Guide for OTX PCMCIA Adapters (Odin TeleSystems Inc. document number 1512-1-HCA-1003-1).

2 Thor-2-ExpressCard Overview

Thor-2-ExpressCard is a dual span T1/E1/J1 adapter in the ExpressCard/54 format. The ExpressCard Standard is promoted by the Personal Computer Memory Card International Association (PCMCIA) and it is quickly gaining ground in today's PC laptop designs.

The Thor-2-ExpressCard is a member of the Odin Telecom framework (OTX) product family. It is supported by the OTX device driver (Window and Linux) and accessed through the OTX Hardware Application Programming Interface (API).

The Thor-2-ExpressCard is equipped with two T1/J1 or E1 interfaces at the speeds of 1.544 Mbps and 2.048 Mbps, respectively. Each interface can be individually configured in T1, J1, or E1 mode. Thor-2-ExpressCard supports all popular frame formats and line coding. In addition to the two T1/E1/J1 interfaces it is also equipped with one Texas Instruments TMS320VC5510 400 MIPS DSP, which can perform many time critical tasks such as HDLC encoding/decoding and tone detection/generation. It is also possible to write custom DSP applications using the OTX C55x DSP Software Development Kit.

Equipped with the appropriate OTX software modules, Thor-2-ExpressCard can be utilized in a variety of T1/E1, Integrated Services Digital Network (ISDN), Frame Relay, Signaling System #7 (SS#7), and Voice over IP (VoIP) applications.

3 Physical specifications

Thor-2-ExpressCard is an extended ExpressCard/54 module designed to be seated in any standard ExpressCard/54 slot. The card measures 54mm (width) x 118.5mm (length) x

18mm (max height). Please see Figure 1:




Figure 1

The green portion of the card is inserted into the ExpressCard/54 slot, and the yellow portion (the bulge) extends beyond the slot.

The bulge contains two RJ48C connectors; one for each T1/E1/J1 span. The two connectors are marked Li0 and Li1, respectively.

Please note that colors indicated in Figure 1 are not the actual colors of the card.

4 Data Architecture

Internally, Thor-2-ExpressCard utilizes serial TDM (Time-Division Multiplexed) data streams for transfer of data or voice. The internal serial TDM data streams are called “Highways.” The external interfaces (E1/T1/J1) are referred to as “spans”.

The Thor-2-ExpressCard physically utilizes 8.192 Mbit/sec TDM highways for data routing.

The DSP can process data from either the incoming E1/T1/J1 spans or from the host by way of DMA transfer via the Burst device. The DSP can supply data to either the outgoing E1/T1/J1 span or to the host by way of DMA transfer via the Burst device. This is described in further details in chapter 4.1 and chapter 4.2.

The physical serial highways provide data paths between physical devices as shown in Figure 2.




Figure 2

The red lines indicate 8.192 Mbps (128 timeslot) highways. The red lines indicate 2.408 Mbps (32 timeslot) highways. The blue lines indicate 1.544 Mbps (T1/J1) or 2.048 Mbps (E1) data. The green lines indicate 32-bit wide parallel data. All data paths are bidirectional.

The highway connection device mixes timeslots from the various sources (T1/E1 devices, the DSP device, and the Burst device) in a fixed pattern. I.e. a certain timeslot of Line Interface 0 will always appear on a certain timeslot on the Burst and DSP highway. Pipes can be created as a logical conduit for data transfer between the different highway devices, but the timeslot selection for the T1/E1 devices is predetermined by the hardware design.

To illustrate the highway/timeslot allocation we show the two highway directions separately. One direction is outgoing data (data that sent from the host (user) application to reach the board, or ultimately, leave the board. The other direction is incoming data (data that will be received by the host application). Please see the following two chapters.

4.1 Outgoing Data

The outgoing data is defined as data that is sent from the host (user application), and which will directly (or indirectly via the DSP) be sent out on the E1 or T1 spans.

The source for the outgoing data can be switched in two different ways. The T1/E1 devices can either be sourced from the DSP device or from the Burst device. The source is determined by the setting of the OTX_ATTR_BRD_FALC_SOURCED attribute.



- OTX_ATTR_BRD_FALC_SOURCED=OTX_BRD_FALC_SOURCED_P2S
Figure 3. In this configuration the T1/E1 devices will get their data from the Parallel to Serial Device (the Burst Device).
- OTX_ATTR_BRD_FALC_SOURCED=OTX_BRD_FALC_SOURCED_DSP
In this configuration the T1/E1 devices will get their data from the DSP device.

The attribute is set by calling the `OtxDrvSetAttributeValueUint32()` function in the OTX HW API. The default setting for this attribute is `OTX_BRD_FALC_SOURCED_P2S`. You can read the value of the attribute by calling `OtxDrvGetAttributeValueUint32()`. For more details of this attribute please refer to the `OtxBrdD.h` header file.

Figure 3 illustrates the highway and timeslot mapping when the T1/E1 devices are sourced by the Burst Device.




Figure 3

Figure 4 illustrates the highway and timeslot mapping when the T1/E1 devices are sourced by the DSP Device.




Figure 4

Please note that the even timeslots (TS0, TS2, TS4, ...) of the Burst Highway have no destination when the T1/E1 device is sourced from the DSP device.

4.2 Incoming Data

The incoming data is defined as data that is read by the host (user application), and which is received on the E1 or T1 spans or generated by the DSP.

The incoming data is not switched. It always has a predefined path. Figure 5 illustrates the highway and timeslot allocation for the incoming data.




Figure 5

Please note that the 32 timeslots from the T1/E1 device are interspersed on an 8.192 Mbps highway on every four timeslot.




- Li0 maps to timeslots TS0, TS4, TS8, ... , TS124 of both the Burst highway and the DSP highway..
- Li1 maps to timeslots TS2, TS6, TS10, ... , TS122 of both the Burst highway and the DSP highway.

Please also not that the highway from the T1/E1 device is always a 2.048 Mbps highway (32 timeslots) no matter if it is configured for E1 or T1. In E1 mode all 32 timeslots are used and mapped to the corresponding timeslot on the E1 span. In T1 mode, TS0 carries the F-bit of the T1 span, and TS1 through TS24 carries the 24 timeslots of the T1 span. Timeslots 24 through 31 of the T1/E1 highway are unused in T1 mode.

5 T1 / E1 Interface Connections

One side of the Thor-2-ExpressCard contains two RJ45/RJ48C connectors. The RJ45 connector provides balanced 100 / 120 ohm transmit and receive connections. The pinout for these two connectors are shown below:



The receive pair is located on pins 1 and 2.

The transmit pair is located on pins 4 and 5.

6 API Supported Physical Devices

6.1 Board Device (OTX_DEVICE_THOR_2_PCI_EXPRESS)

The Thor-2-ExpressCard itself is considered a physical device in the OTX HW terminology. An application should always start by opening the board device (after connecting to the OTX Library).

For a single-board Thor-2-ExpressCard configuration (which would be consider normal in today's PC laptops), the sequence number of the board device would be 0 (zero). In case additional ExpressCard slots are available in the host PC and populated with



additional Thor-2-ExpressCard boards, then each board will be associated with a sequentially higher device number (for instance device number 1 (one) would be assigned to the second Thor-2-ExpressCard board).

6.2 Dual T1/E1/J1 Device (OTX_DEVICE_DUAL_T1E1)

The dual T1/E1/J1 device (OTX_DEVICE_DUAL_T1E1) is the host for the two Li devices (OTX_DEVICE_LI_T1E1). This device must therefore be opened before any of the Li device can be opened.

The sequence number of this device is always 0 (zero).

6.3 T1/E1/J1 Line Interface Devices (OTX_DEVICE_LI_T1E1)

The T1/E1/J1 Line Interfaces (Li) devices handle all of the T1/E1/J1 functionality. There are two Li devices on the Thor-2-ExpressCard; one for each T1/E1/J1 span. Please refer to the OtxT1E1.h and OtxT1E1D.h header files in the OTX HW SDK for the specific API functions available for this type of device.

The two Li devices (OTX_DEVICE_LI_T1E1) are both hosted by the dual T1E1 device (see chapter 6.3). The sequence numbers of these two devices are 0 and 1.

In addition to a standard set of T1/E1/J1 configuration functions the API also offers functions to directly read and write device register values. This feature can be used to configure the device in a customized configuration; not directly supported by the standard OTX HW API.

6.4 Burst Device (OTX_DEVICE_BURST)

The burst device (OTX_DEVICE_BURST) consists of serial to parallel converters and a DMA controller. The application can very efficiently read or write the data directly from the DMA buffers, or have the DMA controller place the data in the host memory and notify the application when data is available. Please refer to the OtxBurst.h and OtxBurstD.h header files in the OTX HW SDK for the specific API functions available for this type of device.

The Burst device (OTX_DEVICE_LI_T1E1) is hosted by the board device (see chapter 6.1). The sequence number for this device is 0 (zero).

6.5 DSP (OTX_DEVICE_DSP)

The DSP on the Thor-2-ExpressCard can be used to run the Standard Program Modules (SPMs) provided in the OTX SDK library. These SPMs, or DSP application packages, provides supports for many common telecom applications; such as tone detection and generation, FSK, and HDLC sending and receiving.

The DSP can also be used to run user developed custom applications. For more information on custom DSP application development, please refer to “*Programmer’s Guide for OTX C54x DSP Software Development Kit*” (Odin document number 1412-1-



SAA-1007-1).

The DSP device (OTX_DEVICE_DSP) is hosted by the board device. The sequence number for this device is 0 (zero).

7 Line Interface Functionality

7.1 Line Configurations

The Thor-2-ExpressCard line interfaces support several different line codes:

- HDB3 - High Density Bipolar 3
- B8ZS - Bipolar 8 Zero Substitution
- AMI - Alternate Mark Inversion
- AMI with NZC

For the T1 operation mode, the following framing formats can be used:

- F4 - 4-frame multiframe
- F12 - 12 frame multiframe (D3/D4, Superframe)
- ESF - Extended Superframe
- F72 - 72 frame multiframe (SLC96 mode)

For the E1 operation mode, Thor-2-ExpressCard supports the following framing formats:

- Doubleframe
- CRC multiframe

7.2 Fault Monitoring

The line interface subsystem supports fault and performance monitoring. The transceiver subsystem detects and reports the following alarms in the receive streams:

- Framing errors
- Cyclic Redundancy Check (CRC) errors
- Code violations
- Loss of frame alignment
- Loss of Signal (LOS)
- Alarm Indication Signal (AIS)
- E bit errors (E1 only)
- Slip
- Remote Alarm Indication (RAI, Yellow Alarm)

The line interface subsystem also supports the transmitting of the following alarms towards the remote end:



- Alarm Indication Signal (AIS)
- Remote Alarm Indication (RAI, Yellow alarm)
- Auxiliary Pattern (AUXP)

7.3 Loop Back

The line interface subsystem implements a remote loop back for line testing. In the remote loop back mode, the clock and data recovered from the line inputs are routed back to the line outputs through the analog transmitter.

8 Testing features

The Thor-2-ExpressCard configuration offers a variety of features to facilitate low-level T1/E1/J1 testing:

- Full access to F, Y, Si, and Sa bits in E1 mode.
- Full access to FS/DL-bits in T1 mode (including support for the DL-channel protocol according to T1.403-1989 ANSI or to AT&T TR54016 specification).
- Programmable line build-out in T1/J1 mode
- Transparent mode
- Programmable transmit pulse shape and receive input threshold
- Insertion and detection of single alarms (e.g. Code Violation, Framing Errors, etc)
- Support for generation and detection of Loop codes
- Support for channel loopback
- Support for PRBS (BERT patterns)

9 ExpressCard Interface

The Thor-2-ExpressCard board is compliant with the ExpressCard/54 bus specification. The board communications flows through the PCI Express 2.5 Gbps interface specified in the ExpressCard standard. The USB interface of the ExpressCard standard is not used in this design.

10 Clocks

On the Thor-2-ExpressCard board, all the internal TDM data highways and the all the devices processing TDM data are synchronized to one clock reference. The clock reference can be derived from multiple sources and then routed to all the devices. The following clocking sources are supported by the Thor-2-ExpressCard:

OTX_CLOCK_SOURCE_INTERNAL - On-board free running oscillator
OTX_CLOCK_SOURCE_LOCAL_0 - Clock extracted from the incoming T1/E1/J1 span 0 (Li0)
OTX_CLOCK_SOURCE_LOCAL_1 - Clock extracted from the incoming T1/E1/J1



span 1 (Li1)

11 JTAG

The Thor-2-ExpressCard contains several JTAG chains which are used for board testing and board configuration during the manufacturing process.

One of the JTAG chains, TMS3, is connected to the DSP and used for a DSP emulator connection when debugging and developing customized DSP software. A special-order case is needed to access the JTAG chains for this purpose. Please contact the Odin TeleSystems Technical Support Team if you want to explore the options to write customized DSP code for this product.

12 Power

The Thor-2-ExpressCard operates from 3.3 Volt and 1.5 Volt power supplied from the ExpressCard slot in host PC. Power consumption is TBD.

13 Certifications

Final certifications are TBD. The Thor-2-ExpressCard will be designed with the following list of planned certifications:

- FCC Part 15 (CFR47, Part 15, Subpart B)
- FCC Part 68
- CE EMC (EN61326-1 Class B Equipment, AS/NZS 2064 Class B Limits)
- Safety EN60950 and UL60950

14 Reference documents

The following documents provide further detailed information related to the Thor-2-ExpressCard board:

- Programmer's Guide for OTX Hardware Driver (Odin document # 1412-1-SAA-1006-1)
- Installation Guide for OTX PCI Adapters (Odin document number 1512-1-HCA-1001-1)
- Programmer's Guide for OTX C54x DSP Software Development Kit (Odin document number 1412-1-SAA-1007-1)

15 Glossary

- OTX – Odin Telecom Framework
- DSP – Digital Signal Processor



- SDK – Software Development Kit
- API – Application Programmer Interface
- CPU – Central Processing Unit. Refers to the host PC (laptop) in this document.
- EEPROM – Electrically Erasable Programmable Read Only Memory.
- FPGA – Field Programmable Gate Array.
- LED – Light Emitting Diode
- LS – Least Significant
- MS – Most Significant